

## ELECTRICAL AND POWER FORMULAS

TO FIND	SINGLE-PHASE	THREE-PHASE	DIRECT CURRENT
<b>KVA</b>	$\frac{E \times I}{1000}$	$\frac{E \times I \times 1.732}{1000}$	-
<b>Kilowatts</b>	$\frac{E \times I \times PF}{1000}$	$\frac{E \times I \times 1.732 \times PF}{1000}$	$\frac{E \times I}{1000}$
<b>Horsepower (Output)</b>	$\frac{E \times I \times \%EFF \times PF}{746}$	$\frac{E \times I \times \%EFF \times 1.732 \times PF}{746}$	$\frac{E \times I \times \%EFF}{746}$
<b>Amperes when HP is known</b>	$\frac{HP \times 746}{E \times \%EFF \times PF}$	$\frac{HP \times 746}{1.732 \times E \times \%EFF \times PF}$	$\frac{HP \times 746}{E \times \%EFF}$
<b>Amperes when KW is known</b>	$\frac{KW \times 1000}{E \times PF}$	$\frac{KW \times 1000}{1.732 \times E \times PF}$	$\frac{KW \times 1000}{E}$
<b>Amperes when KVA is known</b>	$\frac{KVA \times 1000}{E}$	$\frac{KVA \times 1000}{E \times 1.732}$	-
<b>Efficiency</b>	$\frac{746 \times HP}{E \times I \times PF}$	$\frac{746 \times HP}{E \times I \times PF \times 1.732}$	-
<b>Power Factor</b>	$\frac{\text{Input watts}}{E \times I}$	$\frac{\text{Input watts}}{E \times I \times 1.732}$	-

E = Volts      I = Amperes      %EFF = Percent Efficiency      PF = Power Factor

*\* The information contained in this reference is not intended as a substitute for the advice of qualified electrical personnel. Consult an electrician or electrical engineer for verification of any calculations.*